

LOC/DME I-OJW 108.3 Chan 20	APP CRS 183°	Rwy Idg TDZE 54 Apt Elev 56	LDA RWY 20R JOHN WAYNE/ORANGE COUNTY (SNA)
--	------------------------	---	---

DME required.	MALSR	MISSED APPROACH: Climb to 1000 then climbing right turn to 3000 direct SLI VORTAC and hold.
⚠ Circling Rwy 20L NA at night. For inop ALS, increase S-LDA 20R Cat C/D visibility to RVR 6000.	⚠	

D-ATIS 126.0	SOCAL APP CON 121.3 263.1	JOHN WAYNE TOWER ★ 126.8 (CTAF) 0 343.625	GND CON 120.8	CLNC DEL 118.0	CPDLC	UNICOM 122.95
------------------------	-------------------------------------	--	-------------------------	--------------------------	-------	-------------------------

